INSTALLATION IS EASY

Follow these 3 Simple Steps!

STEP 1 »
Sweep Away Debris

STEP 2 »
Fill

STEP 3 »
Compact with Tamp

Always follow safety instructions on back label